


# REPLACEMENT LENS FOR 59466

\*\*\***CAUTION:** Use extreme caution when installing lens as metal edges on cover opening may be sharp.\*\*\*

1. Open the front cover of the dispenser. With the door open, place the lens on the outside of the cover. While looking inside the cover, tip the lens slightly to ensure all three top plastic tabs are positioned so that they hook inside the metal cover opening. (This needs to be done before trying to snap the lens in place.)



2. Snap the lens in place by gently applying pressure near the bottom of the lens from the outside of the cover. (Picture #2). To ensure the lens is securely installed, gently press around the entire perimeter of the lens.



3. Confirm all three top and all three bottom tabs are locked in place. (Picture #3).

